

Super walker

Manual



Notice before using:

1. Whenever you ride the Super walker, you risk serious injury or death from collisions, falls or loss of control. To ride safely, you must read and follow all instructions and warnings in this manual.
2. Note that while the information in this manual will assist you in getting the full benefits of using the Super walker, it can't cover all situations where injury or death may occur. Using the Super walker, you accept the inherent risks when operating this product.


Table of contents:

Structure	Page 2
Introduction	Page 3
Safety instructions	Page 4
Battery use	Page 6
Use of Super walker	Page 7
Maintenance	Page 9
Warranty	Page 9

Notice: When you buy Super walker, don't throw away the outer box and the protecting foam inside it. You need to keep this in case you need to send the Super walker back for service or repair.

Structure:

See the picture below:



Brief introduction

Super walker is a new technical gyro stabilized product which is also the smallest, greenest and most convenient traffic tool. The users can go forward, speed up, speed down, stop with the body leaning. For turning left or right, just twist your body.

Super walker is fashion and cool for outside. It saves space and easy to take. It's a good helper when traveling, going to work, going to school and shopping.

Safety Instructions

Before using Super walker, please inspect whether the function works properly, such as whether there's enough power, the screw of the foot platform loose or whether the platform in the right position.

Always wear a helmet and protective gear when using, in order to protect you when fall down or hurt.

The maximum weight of the rider, including any backpacks or other items that might be carried, must not exceed 110 kilograms.

We don't recommend those who is younger than 15 years old to use this. Even if using this, it's necessary to have adults accompanying to learn or drive.

Don't ride on the steep slopes more than 15°. It may lose traction or brake to hurt you.

Avoid riding on slippery surfaces such as snow, ice, wet floors, wet grass, or any other surface that might cause slipping. Always pay attention to the front when riding. Stop and step off the Super walker over unsafe surfaces or terrain.

Ride on the sidewalk or wide plain area.

Notice:

- Don't ride on the motor way.
- There may be sudden danger when riding. So no matter when you ride, please be careful and respect the rules.

Battery Use

How to charge

- a. Your Super walker comes with a built-in battery pack. Before you use the super walker for the first time, you must fully charge the battery. Be sure to charge the battery in a clean and dry location.
- b. Plug one end of the power cord into the Super-walker. Plug the other end into a grounded AC outlet. The red charging light on the charger unit will turn on.
- c. The charger may take up to 2 hours to complete its charge. The red light on the charger will turn green once it is finished.

Power Level indicator

Once the battery is fully charged, the indicator light on the top of the Super walker will be green when you turn the unit on. The lights' meaning is as following:

- Solid green: the power is more than 70%.
- Slow blinking green: the power is lower than 70%
- Fast blinking green: the power is lower than 40%.
- Fast blinking red: the power is lower than 15% and should be charged.
- Solid red: the power is run out. Do not attempt to ride again until the battery is recharged.

Use of Super walker

Training wheels

Put the training wheel into the groove of the foot platform; fasten the two screws with socket head wrench on the bottom.



Tips for Beginner

When you first learn to use the Super walker, try to install the training wheels and use the learning band. It can be of great help for you to manage the ride feeling. When you are more skilled, you can take the training wheel off. Otherwise, there would be some influence on making turns. For the learning band, when you feel yourself losing your balance and have to step off, you can use the band to keep the Super walker falling off or rolling away.

When you learn Super walker, don't focus your eyes on the wheel or the ground. Keep your body straight and look front.

Please follow the right gesture when riding. Please see the picture below.



Steps for beginners

1. Grab the handle of the Super walker and set it on the ground vertically and turn the power on. The green light on top of the unit will light up. After the buzzer has sound of beep, you can ride. (If your Super walker is lean when you turn the unit on, please let it self correct to vertically then ride.)
2. Unfold the platforms and press them into the down position.
3. Put one foot on one platform and stand up straight. Shifting your weight forward, lightly push off the ground with the other foot and immediately place it on the other platform so that you straddle the Super walker, squeezing the pads between your lower legs.
4. Shift your weight gradually forward to pick up speed. Don't lunge forward.
5. Shift your weight backward to slow down or stop.
6. When you are ready to get off, slow down, stop and step off with one foot; grab the handle. Keep your another foot on the other platform and turn the Super walker off.

Turn

1. At the learning step, try not to turn but just keep straight riding. When you grasp the skills, you would soon learn how to turn.
2. When learning to turn, try to control well the weight on the left and right foot.
3. Don't turn too fast. The platform may scrape on the floor and let you lose the balance and fall.

Get on and off

1. Get on, when you first try to get on the Super walker, try to find wall or guardrail to make you feel balance or you can find someone to help you. When you are more skilled, you can properly not use the additional helper.
2. Get off, you must pay attention to several points when getting off. Notice whether there're people around. Try to slow down when you want to get off. Make sure whether there's obstacle on the road. Don't step too far away for your foot. Just wait it slow to step off.

Speed limit

For your safety, our maximum speed is 15 km per hour. When your speed approaches to 13 km/h, the platform would rise a little with the speeding. When the speed reaches the top, the buzzer would beep. At this moment, please slow down and not speed up any more.

Warning: when the speed approaches to the top, don't lean your body forward to accelerate. This may cause fall and hurt.

Power-off protection

When you lift the Super walker and turn on or the wheel lean more than 45, the buzzer would keep beeping and the indicator would be blinking. For this, it would be automatically shut down. This system is to protect us from hurting by the wheel fast rolling. If you want to ride again, turn on the unit again.

Maintenance

Store your Super walker in a place away from moisture.

If you will not be using the Super walker for an extended length of time, you should fully recharge the battery at least once every 100 days to keep it from draining completely.

Try not to cut down in the middle of charge. That would have influence on the lifetime of the battery.

To clean the Super walker, use a damp cloth and a mild detergent.

Please check whether the screws of the Super walker loose, if so, tighten them with a screw driver.

Should you need a new battery, please contact our authorized service representatives.

Changing the tire

When changing the tire, be sure the power is off.

When you are sure the power is off, please use cross screwdriver and hexagon tools.

Unscrew the 11 screws on one side of the case, then use the hexagon wrench to unscrew the 3 screws on the bottom of the platform and another 3 screws of the holder. The case can be open like this.

After unscrewing all the screws, take the out case to the position that not influencing to take off the tire. Be careful not to stretch the wires inside.

After changing the tire or repair, please check whether the power line lose. Refit the case and fasten the screws.

Warranty

The whole Super walker, besides the battery and vulnerable parts, we guarantee for 1 year. The battery is for 6 months and the tires are for 1 months guarantee.

This warranty does not apply to any product that has been subject to misuse, abuse, negligence or neglect. Defects caused by tampering, alterations and/or repairs are not covered by this warranty.